

Signal Gearbox




Note:

Specification of BFV with limit Switch


1. Indicator light is bright when valve is open fully; Control room give an alarm and indicator light 24V is put out when valve is close to 20° direction.

2. There are two switch in gear box ,one controls indicator light and the other connects to control room.




SWITCH WIRE

OPTION 1



OPTION 2



Dimensions

Size	L	G
50	210	145
65	210	145
80	210	145
100	210	145
125	210	145
150	210	145
200	300	285
250	300	285
300	300	285